



1.PA 直角車縫裝置 PA DEVICE



1.PA 直角車縫裝置 PA DEVICE

序號 Ref. No.	物料編號 Parts No.	名 稱 Description	單位用量 Amt.Req.
1	4PA0000101	空壓管 Vinyl Tube -----	1
2	4PA0000102	氣缸 Air Cylinder -----	1
3	8SE36400806A	螺絲 Screw (SH0530 9/64"-40*6) -----	2
4	4PA0000104	隔環 Spacer -----	2
5	8MB03200606K	螺絲 Screw (CT1207 M3-0.5*6) -----	1
6	4PA0000106	氣缸座 Cylinder Support -----	1
7	4PA0000107	螺帽 Nut (M4-0.7*2.4) -----	1
8	4PA0000108	螺帽 Nut (M2-0.4*1.5) -----	2
9	4PA0000109	針板座 Needle Plate Seat -----	1
10	5221TP00563	針板 Needle Plate -----	1
11	4WPC000101	T形管接頭 T Connector -----	1
12	4WPC000102	空氣管 Air Tube -----	1
13	4PA0000113	左布板 Cloth Plate -----	1
14	4PA0000114	下座前蓋 Front Cover -----	1
15	4WPC000114	節流閥 Speed Controller -----	1
16	4PA0000116	彈簧 Spring -----	1
17	4WPC0001131	支架 Holder Bracket -----	1
18	8MC03201306D	螺絲 Screw (UTB0335 M3-0.5*13) -----	2


2.PA 空壓組件 (A) PA Compressed Air Components (A)



2.PA 空壓組件 (A) PA Compressed Air Components (A)

序號 Ref. No.	物料編號 Parts No.	名 稱 Description	單位用量 Amt.Req.
1	4UTB000301	支架 Cylinder Holder Bracket -----	1
2	8MP06401211A	螺絲 Screw (UTB0302 M6-1*12) -----	4
3	8MK06402314G	螺樁 Stud (UTB0303 M6-1*6) -----	1
4	4UTB000304	氣壓缸 Cylinder -----	1
5	4UTB000305	節流閥 Speed Controller -----	2
6	4UTB000306	氣缸接頭 Joint -----	1
7	8MA08500613A	螺帽 Nut (RP10208 M8-1.25*6) -----	2
8	4UTB000308	揚昇臂 Lifter Arm -----	1
9	2200000716	墊圈 Washer -----	1
10	90ER060	E 形扣環 E Ring -----	1
11	4UTB010311	空氣管接頭 Connector -----	2
12	4UTB010312	空氣管接頭 Connector -----	2
13	4UTB010313	螺絲 Screw (UTB0313 M2.5*0.45*25)-----	4
14	4UTB010314	彈簧墊圈 Spring Washer -----	4
15	4UTB010315	換向閥 Electromagnetic Valve -----	2
16	8MM04282507B	螺絲 Screw (FT0719 M4-0.7*25) -----	2
17	90SW040	彈簧墊圈 Spring Washer -----	2
18	4UTB010318	換向閥座 Electromagnetic Valve Base -----	1
19	4UTG010319	消音器 Silencer -----	2
20	4UTB020266	空氣管接頭 Elbow Connector -----	1
21	8MA08500613A	螺帽 Nut (RP0208 M8-1.25*6) -----	1
22	4UTD000222	軸 Shaft -----	1
23	4UTD000223	螺樁 Stud -----	1
24	8MN04280400A	螺絲 Screw (CT0229 M4-0.7*4)-----	7
25	4UTD000225	承座 Plunger -----	1
26	4UTB01A0255	定位環組 Collar Asm-----	1
27	4UTD0002271	連結桿 Connecting Rod -----	1
28	4UTB020228	絕緣套管 Bushing -----	2
29	4UTB020272	公端子 Power cord -----	2
30	4UTB0003251	軸 Shaft -----	1
31	4UTD000231	球軸連桿 Plunger Connecting Rod -----	1
32	8MA22600729A	螺帽 Nut -----	1
33	4UTD000233	氣壓缸 Cylinder -----	1
34	4UTB000344	節流閥 Speed Controller -----	2
35	8MQ04280808A	螺絲 Screw (UTB0109 M4-0.7*8) -----	3
36	4UTB0003321	基板 Base -----	1
37	4UTD000237	安全開關座 Safety Switch Bracket -----	1
38	8MB04280608A	螺絲 Screw (UTB0130 M4-0.7*6) -----	2
39	4UTB000336	安全開關 Safety Switch -----	1
40	8MC03201606D	螺絲 Screw (UTB03351 M3-0.5*16) -----	2
41	4UTB010337	曲柄 Tension Release Lever -----	1
42	4UTD000242	支架 Holder Bracket -----	1
43	8MB04280908G	螺樁 Stud (UTB0339 M4-0.7*8) -----	1
44	8MB03200506K	螺絲 Screw (CT0525 M3-0.5*5) -----	2
45	4PA0000245	連桿 Connecting Plate -----	1
46	8MP05321210A	螺絲 Screw (UTB0340 M6-1*12) -----	2
47	4UTD000247	連結塊 Connecting Block -----	1
48	4UTD000248	氣缸座 Cylinder Barcket -----	1
49	4UTB010245	定位環 Collar -----	1
50	8MC95300606F	螺絲 Screw (CT0823 M4.5-0.75*5) -----	1
51	4UTB000346	彈簧 Spring -----	1
52	4UTD000252	空壓組件座 Trimming Cylinder Support -----	1
53	8MM06401210A	螺絲 Screw (FT1103 M6-1*12) -----	3
54	4UTD000254	線夾 Cord Clamp -----	1
55	8MC04280807D	螺絲 Screw (CT0130 M4-0.7*8) -----	1
56	4PA0000256	氣壓缸 Cyliner -----	1
57	4STB000121	節流閥 Speed Controller -----	2
58	4PA0000258	接頭 Joint -----	1
59	4PA0000259	接頭 Joint -----	1
60	8MA04280307A	螺帽 Nut -----	2
61	4PA0000261	銷 Pin -----	1
62	4PA0000262	C型扣環 C-Ring -----	2
63	4UTB01A03491	換向閥組 Electromagnetic Valve Asm -----	1
64	8MA03200306A	螺帽 Nut (FTB0111 M3-0.5*3) -----	2
65	4UTB01A0350	氣壓缸組 Cyliner Asm-----	1
66	4UTD01A0257	氣壓缸組 Cyliner Asm-----	1
67	4UTB010353	墊圈 Washer -----	4
68	4UTB010152	定位環 Collar -----	1


3. PA 空壓組件 (B) PA Compressed Air Components (B)



3. PA 空壓組件 (B) PA Compressed Air Components (B)

序號 Ref. No.	物料編號 Parts No.	名 稱 Description	單位用量 Amt.Req.
1	4TC00103011	楔片座 Wedfe Seat -----	1
2	8WD30000015B	木螺絲 Wood Screw -----	2
3	4PA000A0303	換向閥 Electromagnetic Valve -----	1
4	8MC03202006D	螺絲 Screw (FTC10304 M3-0.5*20) -----	2
5	4TC0010305	空氣管 Air Tube -----	1
6	4PA0000306	電源線 Cable -----	1
7	4TC001A0310	膝控開關組 Knee Switch, Complete Set -----	1
8	2206110226	T型管接頭 T Connector -----	1
9	4PA0000309	快速接頭 Connector -----	2
10	4PA0000310	消音器 Silencer -----	2
11	4UTB000312	快速接頭 Connector -----	1
12	4PA000A0312	換向閥組 Electromagnetic Valve Asm. -----	1
13	4PA0000314	線圈 Solenoid (DC 24V) -----	1
14	4PA0000315	換向閥 Electromagnetic Valve -----	1

4. PA 鬆線機構及更換零件 Thread Tension Components And Motor Components For PA



4.PA 鬆線機構及更換零件 PA Thread Tension Components And Motor Components

序 號 Ref.No.	物料編號 Parts No.	名 稱 Description	單位用量 Amt.Req.
1	4UTB020308	止動桿 Stopper -----	1
2	8MN06400600A	螺絲 Screw (CT0244 M6-1*6) -----	2
3	4UTB020303	針定位器 Synchronizer -----	1
4	4UTB02A0304	針定位器組 Mount- on Type Synchronizer -----	1
5	4UTB02A0305	止動桿組 Stopper Set Asm. -----	1
6	4UTB020306	束線 Plastic Binding Wire -----	2
7	4UTB020307	六角板手 Allen Key -----	1
8	8MC04281007A	螺絲 Screw (FT0217 M4-0.7*10) -----	1
9	4UTD0003091	防塵蓋 Dust Cover -----	1
10	4UTB000410	曲柄 Tension Release Shaft -----	1
11	4UTB000411	彈簧 Spring -----	1
12	4UTB000412	接頭 Pin -----	1
13	8MN03200300A	螺絲 Screw (CT0115 M3-0.5*3) -----	(see the table)
14	4UTB000414	彈簧 Spring -----	1
15	2200001025	墊圈 Washer -----	1
16	90ER030	E 形扣環 E Ring -----	1
17	8MB04280507K	螺絲 Screw (FT0235 M4-0.7*5) -----	2
18	4UTB000418	導線 Thread Guide Eyelet -----	1
19	4UTB000419	鬆線滑板 Release Wedge -----	1
20	4UTB000420	導線座 Tension Post Support -----	1
21	8MM04281607A	螺絲 Screw (FT0202 M4-0.7*16) -----	2
22	4UTB000422	隔環 Spacer -----	2
23	4UTB000423	導桿 Guide Bar -----	1
24	4UTB000424	鬆線桿 Release Bar -----	(see the table)
25	4UTB000425	鬆線座 Thread Pull-off Block -----	(see the table)
26	8MC03201006D	螺絲 Screw (UTB0426 M3-0.5*10) -----	2
27	4PA0000313	中繼線 Connecting Cable -----	1
28	4UTD000328	端子座固定架 Terminal Holder Support -----	1
29	4PA00001111	封蓋 Rear Cover -----	1
30	-----	-----	-
31	4UTB010456	8mm空氣管接頭 Connector -----	2
32	4UTB0004321	調壓濾水閥 Regulator -----	1
33	66668	平口起子 Screwdriver -----	1
34	4UTB000434	鬆線座 Thread Pull-off Block -----	(see the table)
35	4UTB000435	導線 Thread Guide Eyelet -----	2
36	8MB03200306X	螺絲 Screw (UTB0436 M3-0.5*3) -----	2
37	4UTB00A04582	調壓濾水閥組 Regulator Asm.-----	1
38	8WD30000015B	木螺絲 Wood Screw -----	2
39	4UTB010430	空氣管 Air Tube -----	1
40	66635	六角板手 Allen Key 2MM -----	1
41	66640	六角板手 Allen Key 2.5MM -----	1
42	4UTD000343	手輪 Handwheel -----	1
43	4UTB000444	磁鐵 Magnet -----	2
44	8MN06400800A	螺絲 Screw (CT0549 M6-1*8) -----	1
45	8MN06401100C	螺絲 Screw (CT0548 M6-1*11) -----	1
46	4UTB000447	內藏式定位器 Built-in Type Synchronizer -----	1
47	8MB04280608A	螺絲 Screw (UTB0130 M4-0.7*6) -----	2
*48	4UTB02A0347	外置式定位器組 Mount- on Type Synchronizer Set-----	1
*49	/BS002	內藏式定位組 Built-in Type Synchronizer -----	1
50	4UTB02A0349	鬆線組 Thread Tension Mechanism-----	1
51	4UTD000351	擺動臂 Rocker Arm -----	1
52	-----	-----	-
53	4UTB010459	墊圈 Washer -----	1
54	-----	-----	-

Ref. No.	13	24	25	34
2Needle without Spreader	8pcs.	4pcs.	2pcs.	1pcs.
3Needle without Spreader	10pcs.	5pcs.	3pcs.	1pcs.
2Needle with Spreader	11pcs.	6pcs.	2pcs.	2pcs.
3Needle with Spreader	13pcs.	7pcs.	3pcs.	2pcs.

*: 選購,並須配合伺服馬達使用 <型號HVP-60,HVP-70,HVP-90>

*: To choose and purchase: These two devices should be used together with AC servo motor <Model No:HVP-60,HVP-70,HVP-90>