


## EG006 導邊器 EDGE GUIDE DEVICE

FOR (UH9003F/UHD9003F/UH9303/UHD9303/UHF9303/UHU9303)

(UH9004F/UHD9004F/UHF9004/UHU9004/UH9304/UHD9304/UHF9304/UHU9304)



## EG006 導邊器 Edge Guide Device

FOR (UH9003F/UHD9003F/UH9303/UHD9303/UHF9303/UHU9303)

(UH9004F/UHD9004F/UHF9004/UHU9004/UH9304/UHD9304/UHF9304/UHU9304)

| 序號<br>Ref. No. | 物料編號<br>Parts.No. | 名<br>Description | 稱                  | 單位用量<br>Amt. Req. |
|----------------|-------------------|------------------|--------------------|-------------------|
| 1              | /EG006            | 導邊器組             | Edge Guide Set     | 1                 |
| 2              | 4EG0060103        | 導邊               | Edge Guide         | 1                 |
| 3              | 2120000150        | 波形墊圈             | Waved Washer       | 1                 |
| 4              | 8SC36400707D      | 螺絲               | Screw              | 3                 |
| 5              | 4EG0010107        | 墊圈               | Washer             | 1                 |
| 6              | 4EG0060108        | 導邊座              | Edge Guide Bracket | 1                 |
| 7              | 8SC44400908E      | 螺絲               | Screw              | 1                 |
| 8              | 4EG0060109        | 活頁               | Hinge              | 1                 |
| 9              | 8SB32440605K      | 螺絲               | Screw              | 1                 |
| 10             | 4EG0060112        | 支架               | Bracket            | 1                 |
| 11             | 4BH0020109        | 定位凸輪             | Cam                | 1                 |
| 12             | 8MC04281207D      | 螺絲               | Screw              | 1                 |
| 13             | 2100000223        | 墊圈               | Washer             | 1                 |
| 14             | 8SA44400307A      | 螺帽               | Nut                | 1                 |
| 15             | 4EG0060117        | 墊圈               | Washer             | 2                 |