


EF006 鬆緊帶張力調整機構 ELASTIC TAPE ATTACHING



EF006 鬆緊帶張力調整機構 Elastic Tape Attaching

序號 Ref. No.	物料編號 Parts No.	名稱 Description	單位用量 Amt. Req.
1	4EF0060101	變速機座	Transmission
2	4EF0060102	上蓋	Cover
3	4EF0060103	鬆緊帶傳送滾輪組	Elastic Asm.
4	4EF0060104	齒形皮帶輪	Timing Gear
5	8MN05320500E	螺絲	Screw
6	4EF0060106	齒形皮帶	Timing Gear (228XL*12MM)
7	4EF0060107	支架	Bracket
8	8MM05320809A	螺絲	Screw
9	4EF0060109	皮帶護蓋	Belt Cover
10	8MC04280507D	螺絲	Screw
11	4EF0060111	皮帶輪	Pully
12	8MN06400800C	螺絲	Screw
13	4EF0060113	連結軸	Shaft
14	4EF0060114	齒形皮帶輪	Timing Gear
15	2200001025	墊圈	Washer
16	4EF0060116	手輪	Hand Wheel
17	8MM06404310B	螺絲	Screw
18	4EF0040107	墊圈	Washer
19	8MM06401210A	螺絲	Screw
20	8MN06400800A	螺絲	Screw
21	4EF0060155	螺帽	Nut
22	4EF0060156	調整架	Bracket
23	4EF0060157	導線桿	Thread Guide
24	4EF0060158	螺絲	Screw
25	4EF0060159	支撐架	Bracket
26	4EF0060126	皮帶蓋	Belt Cover
27	8MC05321209D	螺絲	Screw
28	4EF0060154	支架	Bracket
29	8MA06400510A	螺帽	Nut
30	90PW040	墊圈	Washer
31	8MM04281207A	螺絲	Screw
32	*****	壓腳組	Presser Foot Asm.
33	8MM05321609A	螺絲	Screw
34	4EF006A0106	鬆緊帶組	Elastic Asm.
35	*****	壓腳組	Presser Foot Asm.
36	4BH0030101	承座	Bracket
37	8SC44401109E	樞銷螺栓	Screw
38	4BH0020104	波形墊圈	Waved Washer
39	8SA44400307A	螺帽	Nut
40	4BH0020106	定位銷	Pin
41	4BH0020107	簧片	Spring
42	8SC32440406A	螺絲	Screw
43	4BH0020109	定位凸輪	Cam
44	8SB32440505A	螺絲	Screw
45	8MC04281207D	螺絲	Screw
46	4EF0060146	活動臂	Arm
47	8MA05320408A	螺帽	Nut
48	4EF0060148	連桿	Connection
49	2210090314	右導模	Tape Guide (R)
50	4EF0060150	導模滑桿	Tape Guide Bar
51	8MN03200300A	螺絲	Screw
52	4EF006A0146	導帶組	Thread Gear Set

***** 詳細資料請參照左圖
 ***** See Left Page