



EF017 鬆緊帶張力調整機構 ELASTIC TAPE ATTACHING (FOR UHD9383 UHD9384)



壓腳組 Presser Foot Asm.		
機型 Models	5212PF0801	5212PF0802
	UHD9383-053-H04	UHD9384-243-H14

EF017 鬆緊帶張力調整機構

Elastic Tape Attaching (For UHD9383 UHD9384)

序號 Ref. No.	物料編號 Parts No.	名 Description	稱	單位用量 Amt. Req.
1	4EF0160101	變速機座	Transmission	1
2	4EF0160102	上蓋	Cover	1
3	4EF0060103	鬆緊帶傳送滾輪組	Elastic Asm.	1
4	4EF0060104	齒形皮帶輪	Timing Gear	1
5	8MN05320500E	螺絲	Screw	6
6	4EF0060106	齒形皮帶	Timing Gear (228XL * 12mm)	1
7	4EF0070101	支架	Bracket	1
8	8MM05324507A	螺絲	Screw	2
9	4EF0060109	皮帶護蓋	Belt Cover	1
10	8MC04280507D	螺絲	Screw	4
11	8MM05324507A	螺絲	Screw	1
12	8MA05320408A	螺帽	Nut	1
13	4EF0060113	連結軸	Shaft	1
14	4EF0060114	齒形皮帶輪	Timing Gear	1
15	2200001025	墊圈	Washer	2
16	4EF0060116	手輪	Hand Wheel	1
17	8MM06404310B	螺絲	Screw	1
18	4EF0040107	墊圈	Washer	1
19	8MM06401210A	螺絲	Screw	3
20	90PW040	墊圈	Washer	3
21	*****	壓腳組	Presser Foot Asm.	1
22	8MM05321609A	螺絲	Screw	2
23	4EF007A0106	鬆緊帶組	Elastic Asm.	1
24	*****	壓腳組	Presser Foot Asm.	1
25	4BH0030101	承座	Bracket	1
26	8SC44401109E	樞銷螺栓	Screw	1
27	4BH0020104	波形墊圈	Waved Washer	2
28	8SA44400307A	螺帽	Nut	1
29	4BH0020106	定位銷	Pin	1
30	4BH0020107	簧片	Spring	1
31	8SC32440406A	螺絲	Screw	1
32	4BH0020109	定位凸輪	Cam	1
33	8SB32440505A	螺絲	Screw	1
34	8MC04281207D	螺絲	Screw	1
35	4EF0060146	活動臂	Arm	1
36	8MA05320408A	螺帽	Nut	1
37	4EF0060148	連桿	Connection	1
38	2210090314	右導模	Tape Guide (R)	1
39	4EF0060150	導模滑桿	Tape Guide Bar	1
40	8MN03200300A	螺絲	Screw	2
41	4EF006A0146	導帶組	Thread Gear Set	1
42	8MN06400800A	螺絲	Screw	3
43	4EF0060155	螺帽	Nut	1
44	4EF0060156	調整架	Bracket	1
45	4EF0060157	導線桿	Thread Guide	1
46	4EF0060158	螺絲	Screw	1
47	4EF0060159	支撐架	Bracket	1
48	4EF0060154	支架	Bracket	1
49	8MA06400510A	螺帽	Nut	1
50	8MM04281207A	螺絲	Screw	2
51	4GC0600132	套管	Thread Guide	4
52	2120001240	墊圈	Washer	4

***** 詳細資料請參照左圖

***** See Left Page