

CHAIN & WASTE REMOVAL CYLINDER FOR PRESSER FOOT ASSEMBLY



CV28F-2 真空吸風切線線屑集塵組**廢布收集組&三方位空氣/氣缸抬壓腳****Chain & Waste Removal Cylinder For Presser Foot Assembly FOR (UHD9300)**

序號 Ref. No.	物料編號 Parts.No.	名 Description	稱	單位用量 Amt. Req.
1	B-100	真空送氣組	Vacuun Chain Removal	1
2	C-300	廢布&線頭收集組(布袋)	Waste & Lint Gather System (Fabric Bag)	1
3	D-200	吸線屑&吸布屑主座	Waste & Lint Remover Funnel	1
4	4CV0800101	抬壓腳用-氣缸組 (UH9000用)	Air Cylinder For Presser Foot Assembly	1
5	4CV0060126	調壓閥組(含公、母接頭)	Filter/Regulator	1
6	4TC012016	Y型三通接頭	Y Connector	1
7	4CV08F0101	固定座	Bracket	1
8	8MC03204506D	螺絲	Screw	2
9	4CV08F0102	電磁閥	Electrical Controller	1
10	4CV08F0103	電磁閥	Electrical Controller	1
11	4TT-S34033	連接器套頭6P	Power Cord Cap	1
12	4AL013013	連接器套頭2P	Power Cord Cap	1
13	4AL013015	2P母端子	Power Cord	4
14	4TT-S34032	6P母扣連接器	Power Cord	1
15	4AL013017	2P母扣連接器	Power Cord	1
16	CV28B-2	真空吸風切線線屑集塵組&廢布收集組附調壓閥組(含公、母接頭) Chain & Waste Removal Assembly & Filter/Regulator		1
17	4CV0800101-2	單動氣缸組(含螺帽)	Air Cylinder Asm. (Nut)	1
18	4CV0800101-1	氣缸支架	Cylinder Holder	1
19	4AL0070102	套筒	Clutch Sleere	1
20	CV28B-1	真空吸風切線線屑集塵組&廢布收集組 Chain & Waste Removal Assembly		1
21	4CV08FA0103	電磁閥組	Electrical Controller Asm.	1
22	K-100	真空送氣管	Venturi Tube	1
23	8WD45001900A	螺絲	Screw	6
24	8MP06401011A	螺絲	Screw	2
25	4TC0010130	φ6空氣管	Air Tube (L=1000mm)	5

* 必須配合直驅馬達使用 (型號: TD)

* These two devices must be used together with liner-motor (Model No: TD)