


TR023 擴張滾輪組零件列表 PARTS LIST FOR TR023 ROLLER SET
 FOR (UH9303/UHD9303/UHF9303/UHU9303)
 FOR (UH9304/UHD9304/UHF9304/UHU9304)



TR023 擴張滾輪組零件列表 Parts List For TR023 Roller Set**FOR (UH9303/UHD9303/UHF9303/UHU9303)****(UH9304/UHD9304/UHF9304/UHU9304)**

序號 Ref. No.	物料編號 Parts.No.	名 Description	稱	單位用量 Amt. Req.
1	4TR0120113	定位塊	Setting Block	1
2	4TR0120114	定位塊	Setting Block	1
3	4TR0220101	滾輪座	Roller Seat	1
4	4TR0120104	前滾輪臂	Roller Holder Arm	1
5	4TR0170101	滑軌	Guide	1
6	4TR0170103	滾輪	Roller	1
7	4TR0120107	軸	Shaft	2
8	4TR0120108	滾輪	Roller	2
9	4TR0120109	定位環	Collar	4
10	2130000360	平墊圈	Washer	1
11	8MC04280607D	螺絲	Screw	1
12	4TR0020120	滾輪臂	Roller Holder Arm	1
13	8MN03200300A	螺絲	Screw	4
14	8SC44401008A	螺絲	Screw	1
15	4TR0020119	螺樁	Stud	1
16	8MM05324507A	螺絲	Screw	2
17	4TR0020128	柄	Handle	1
18	8MC04281007D	螺絲	Screw	4
19	2120000151	墊圈	Washer	4
20	4TR0020129	止動塊	Tension Roller Slider Stop	1
21	2120000527	平墊圈	Washer	8
22	8MM05321009A	螺絲	Screw	2
23	2120001240	墊圈	Washer	4
24	8MA05320408A	螺帽	Nut	2
25	8MC04282007D	螺絲	Screw	4
26	8MC05320809A	螺絲	Screw	2
27	4TR019A0102	滾輪組	Roller Asm.	1
28	8MC05321209D	螺絲	Screw	2
29	4TR023A0101	滾輪組	Roller Asm.	1